

PC-100 FAIL SAFE


APPLICATION BRIEF

DISABLE FIRST STAGE

This circuit allows you to disable
the first stage of the fail safe feature.

**It adds one count to the input
each time you push the start button.**

Add Jumper between terminals 6 & 10



NOTES:

Function 50 must be programmed for a 1 or 2.
The second input (terminal 10) cannot be used for anything else.
Program function 30 for normal second stage fail safe time delay.



BadgerMeter, Inc.

P. O. Box 245036 Milwaukee, WI 53224-9536
Telephone: (414) 355-0400
Fax: (414) 355-7499